

Operation Manual

GP3600PD



Translation of the original operation manual

*The picture serves for reference only and it may not represent an exact match of the device delivered

EN

CONTENTS

Product use in compliance with its determination.....	pg.	1
Safety.....	pg.	1
Scope of the supply.....	pg.	2
Assembly.....	pg.	2
Entry into service.....	pg.	3
Engine.....	pg.	3
Engine maintenance.....		
Pump.....	pg.	6
Help with failures.....	pg.	11
Guarantee.....	pg.	11
Technical data.....	pg.	13
Declaration of compliance with EU standards....	pg.	14



WARNING

Read this original manual of use and included safety instructions before the first usage of your new device. Act accordingly. Keep the manual for a later usage or for another owner of the device.

Product use in compliance with its determination

This high-pressure washer can be used:

- For washing of machines, vehicles, buildings, tools, facades, building exteriors, garden tools etc., along with the high-pressure stream of water (in case of need with adding detergents);
- With accessories and spare parts approved by the company Waspper s.r.o..
- In the environment without any direct exposure to the splashing polluted water with the solid particles.
- The device has to be stored in the environment protected against the weather conditions.

Environment protection



Package materials can be recycled. Dispose the package according to the ecological rules.

Old machines contain evaluable recycling substances, which should be reused again. The old machines have to be disposed ecologically.

Cleaning operations, out of which waste water with oil content arise e.g. during engine cleaning or cleaning of the machinery floor, can be executed only in the washrooms with the oil separators. You can execute the work with detergents only on workplaces sealed to be impermeable to fluids outflow and attached to the sewer system for the polluted water. Avoid emission of detergents to the aquatic resources or soil.

Safety

Safety instructions

Before you use this device for the very first time, unconditionally read included "Safety instructions for the high-pressure washers".

Acoustic protection devices and eye protection devices are appropriate to use during operation of the

washer for the purpose of acoustic and eye protection.



Levels of danger



DANGER - Warning before imminent danger, which may cause serious injuries or death.



WARNING - Warning before a possible dangerous situation, which could result in minor injuries.

WARNING - Warning before a possible dangerous situation, which could result in material injuries.

Safety elements



WARNING - Safety elements serve for the user protection against injuries and they mustn't be altered or withdrawn from their operation. In case of damage, they have to be replaced only by an original spare part.

Security covers of hot or rotating parts



Security covers serve for protection of the high-pressure washer against injuries resulting from the high temperatures of some parts of combustion engine or against the injury caused by the rotating parts of the device.

Security features of the combustion engine and pump

Safety switch of the low level of engine oil serves for an automatic engine shutdown in case the oil level decreases below the minimal level. We avoid the engine damage caused by insufficient lubrication of internal parts in this way. However, this safety element does not substitute the obligation to check oil level before usage of the device.

Further important information is in the part – ENGINE (pg. 3).



Temperature indicator placed on to the pump serves for engine protection against the water with the temperature higher than the maximum operating temperature of the engine.

Scope of the supply

Content of the delivery device is portrayed on the package or in the order of goods. After unpacking check the completeness of the content. If some parts are missing or you find damages arisen during the transport, please, inform the seller about it.





It is required additionally

Clean water resource for direct supply of the pump by pressurised-water with the amount of 22L/min and minimum pressure of 2 bar.



Assembly

The single device is assembled in the production plant. Complete the pressure gun, extension piece and nozzle. Attach the high-pressure gun at the ending of the high-pressure hose. In the next step it is necessary to fill up the engine with delivered engine oil according to the instructions in this section **ENGINE (pg.3)** and pour fresh fuel – diesel.



1. Unpack Pressure Washer.

1.1 Set carton on a rigid, flat surface. Remove all loose parts and packing.

Leave pressure washer in carton.

WARNING ! Unit is heavy. Do not attempt to lift and remove the pressure washer unit from the carton.

1.2 Using a box cutter, open carton completely by cutting the four corners allowing the sides to lay flat. Leave pressure washer on carton while installing wheel, leg rubber bumpers.

2. Assembly the Wheel

2.1 Remove the nut, spring washer and washer from the axle.

2.2 Fit the axles into the wheel axle ports, secure with the nut, spring washer and washer.

2.3 Lift the machine and fit the axles into the axle ports that are at the bottom of the frame, and ensure the nipple of the spring clip is clocked into the small hole.



NOTE: Do not overtighten the nuts, the wheels must be able to rotate freely.

4. Assembly the Gun/Hose Hook

4.1 Fit the hook into the position shown and secure using the washers and nuts on the bracket

5.0 Preparing Pressure Pump

The pressure pump has a shipping plug inserted into the opening for the pump breather plug.



Supply with water

WARNING The water has to be clean, with 2 bar minimum pressure without solid particles or mud. Polluted water damages internal components of the high-pressure pump. Unless the pump exerts the pressure until 30 seconds after engine start-up, switch off the engine and proceed according to the instructions in the section Problems solution! Dry run for more than 30 seconds causes pump damage!

Damages on the equipment for the reason of failing to obey this instruction result in the termination of the guarantee.

Engine



Oil plug with gauge

It is **NECESSARY** to pour the right amount of the supplied engine oil to the engine before the first start-up of the pump. Packed engine oil bottle **can contain bigger amount of the filler** than it is necessary for the given type of the engine. The exact amount of the filler is laid down in the technical specification. We advise to decrease the outlet pressure of the water according to the instructions on the **page 8** for smoother start-up of the cold engine.

Place the pump on the horizontal surface. Open the plug of the oil sump where the oil dipstick is located. Pour around $\frac{3}{4}$ of the required amount of the oil to the engine. Screw the plug in the engine. At the position of the switch **C** in the position **OFF (0)** (picture at the bottom) rotate the engine by pulling the start-up lead. Open the plug, wipe the dipstick and check the engine oil level.

CAUTION: The dipstick shows the correct oil level only after the full screwing up to the engine cutout. Pour in the oil in the way, so the oil is in the proximity of MAX mark.

Open the plug of the tank and pour the fuel into the tank. The old fuel has different physical characteristics and can cause the engine hunt or the decreased pumping capacity. **Use only the clean fuel without oil additions**

- **Your engine is of four-stroke type.**



DANGER

Running engine produces the carbon monoxide, colorless and poisonous gas without odor.

Inhalation of carbon monoxide may cause nausea, headache, dizziness, vomiting and death!

The device can be used only in the outer environment where the proper ventilation is ensured. It is also necessary to ensure that the exhausted gases wouldn't get to the closed rooms through unsealed hatchways.

If you work with the running engine, turn the device in the direction so that the standing people and hatchways of the buildings (garages, porches, cellars etc.) do not face the exhaust pipes.

The engine produces the waste heat during operation which results in the presence of many hot components (exhaust, engine cylinder), which can cause the serious burns in case of touching. There is a fire hazard if these hot components come into contact with flammable materials.



DANGER

Diesel vapors are extremely flammable and explosive and in case of the wrong manipulation they can cause burns, fire or explosion.


Let the engine cool down for 5 minutes before pouring the fuel into the tank. Then open the tank hood and start to pour the fuel to the tank carefully. **NEVER** fill up the fuel to the edge because it heats and spreads during engine usage and that can cause the fuel leakage through the plug followed by the explosion or fire. **NEVER** turn over the high-pressure device to the position where the fuel could leak from the tank.

NEVER try to start up the engine if the components of fuel supply, ignition components or security features are damaged.

Warning! While starting the engine, the gun control lever must be depressed and the water pressure released from the system otherwise battery safety fuse will blow and the starting will be not possible. Blown fuse is not covered by warranty!



Starting the Engine:



To start your pressure washer for the first time, follow these instructions step-by-step.

1.1 Place pressure washer near an outside water source capable of supplying water at a flow rate at least 5 gallons per minute and no less than 20 PSI at pressure washer end of garden hose.

1.2 Check that high pressure hose is tightly connected to spray gun and pump.

1.3 Make sure unit is in a level position.

1.4 Uncoil high pressure hose completely before using pressure washer.

1.5 Connect garden hose to water inlet on pressure washer pump.

1.6 Turn ON water, point gun in a safe direction and push the trigger to purge pump system of air and impurities.

1.7 Attach wand to spray gun. Tighten by hand.

1.8 Choose the nozzle, pull back on collar of quick connector, insert nozzle and release collar.

1.9 Rotate fuel valve to "On" position

1.10 Turn the engine speed control knob (A) to the left (B). Slide the engine speed control knob to the START position (C). Turn the engine speed control knob to the right (D) to tighten it.

1.11 Connect the positive and negative cable to the battery terminal.

2. Electric Start

Turn the Key clockwise to the START position. Release the key as soon as the engine starts. It will return to the ON position.

NOTE: If the engine fails to start:

1) Wait until the engine complete stops.

Engaging the starter while the engine is rotating will damage the start motor and flywheel.

2) Wait at least 30 seconds before you attempt to start the engine again.

IMPORTANT: Allow the Engine to run at no load, low pressure for five minutes after each start-up so Engine can stabilize.

3. Recoil Start

See the engine manual for instructions on how to recoil start the engine.

4. Cold Start in winter

ENGINE SWITCH OFF

If the engine is difficult to start in winter, see the engine manual for instructions on how to cold start.

5.1 Release spray gun trigger and allow the engine to run unloaded for 3 minutes before shutting down.

5.2 Stop the engine by turn the engine sped control knob to the left (B), slide the knob to the STOP (A) position, turn the knob to the right (D) to tighten it.

5.3 Turn the engine switch to the "OFF" position and remove the key.

5.4 Rotate fuel valve to "OFF" position

5.5 Point spray gun in a safe direction, push spray gun trigger to release retained high water pressure. Engage the gun trigger safety catch.

MAINTENANCE

After first 5 hours	Change engine oil
Every 8 hours or daily	Engine oil level check Air filter area check and check of the impurities from the exhaust.
Every 50 hours or at the end of the season	Clean the air filter Change of engine oil
Every 100 hours	Checking and setting up the electrode of the sparking plug. Checking fuel lines

During operation, in certain cases, the protective covers made of tin can be released because of vibrations. These components need to be tightened because an action of long-term vibrations on the released cover causes the damage of fixing holes. In case the protective cover of the exhaust, air filter or cooling fan is damaged, these parts have to be replaced by the original spare parts because only in this case the maximum operation safety can be ensured.

Spare parts are available through the producer or certified service point. Complete list of the components is published in this manual or on the Internet sites of the producer.

Winter storage

Correct long-term storage is a key to attain trouble free operation in the next season. You prolong the service life of the engine by the correct storage.

Following steps provide the maximal engine components protection against corrosion and wear of the engine slide parts.


The engine cannot run and engine temperature has to be lower than 50°C. Clean the engine from dust and impurities with a wet cleaning rag. Clean potential damages with paint or an oily rag after drying. In this way you prevent the tin from interaction with the air, followed by corrosion.

Open the fuel tank plug and check the amount of the fuel in the tank. Long-term presence of the fuel in the tank during storage has a negative impact on the fuel quality. It can result in engine hunt or decreased engine power.

Discharge the fuel from the tank. **DONOT TURN ENGINE OVER.**

THERE IS A DANGER OF OIL LEAKS! We advise to change the engine oil at the end of the season. The service life of the engine will be prolonged.

Change of engine oil




We advise to change the engine oil after use of the device (according to the maintenance plan). Switch off the engine. Let the device cool a little bit, so the temperature is lower than 50°C. You will avoid potential burn injuries. It is

appropriate for the engine to remain warm. **The warm oil leaks out from the engine more easily.**

- Unscrew the OIL PLUG WITH THE DIPSTICK.
- Place the pot of the minimal volume of 1,5L under the relief valve screw.
- Release the relief valve screw carefully.
- Let the oil flow out freely to the prepared pot.
- If the oil already stopped leaking, decline the engine mildly so that the rest of the oil would leak.

Clean the area of the relief valve screw and tighten it back to its original place.

-  Used engine oil is necessary to hand in some of the collection centres for this purpose. **The engine oil is dangerous waste!**



Pour the right amount and type of the engine oil into the engine. The oil specification is laid down below. - The accurate amount of the oil is written in the Technical specification.

- Place the pump on the horizontal surface. Pour around $\frac{3}{4}$ of the required amount of the oil to the engine. Screw the plug in the engine. At the position of the switch **C** in the position **OFF (0)** (picture at the bottom) rotate the engine by pulling the start-up lead. Open the plug, wipe the dipstick and check the engine oil level.

CAUTION: The dipstick shows the correct oil level only after the full screwing up to the engine cut out. Pour in the oil in a way that the oil is in the upper part, in close proximity of MAX mark.

The engine oil is one of the key factors influencing power and service life of the engine.

Minimal requirements for oil are: Viscosity class 5w30, 10W30 or 10W40 with the quality class at least SF and more (SG, SH, SJ). The usage of the engine oil 10W30 in temperatures higher than 27°C can result in the higher oil consumption. That is why it is important to pay higher attention to the oil level if the device operates under these temperatures and oil 10W30. In such as cases we recommend to use the oil 10W40 of the quality class SF and higher (SG, SH, SJ). The delivered engine oil exceeds the minimal requirements for the quality highly and ensures the safe engine operation with the minimal wear of the internal parts under the tough operating conditions.

If the engine oil is necessary to be refilled, use only the same type and brand-mark already present in the engine. Mixing of different oil types is not recommended!

Pump

Your pump is of all-metal character and so it ensures the long service life and non-fault run. There are moving parts with their accurate location in the pump. Because of that fact it is NECESSARY that the water coming into the pump would be without mechanical impurities. These impurities abrade the landing areas of the pump, by means of which clearance between the internal components increases and the outlet pressure decreases.



DANGER

The pump generates too high pressure in the outlet and as the result the blowing water



has devastating effects on soft objects. Aiming water jet at people or animals IS FORBIDDEN. Failing to obey this warning can have devastating effects with the results such as permanent blindness, cut wounds, amputations and death.




CAUTION!

The high pressure can cause damages on soft and sensitive objects. It is not recommended to use the water jet with the high pressure to clean rubber and tyres, glass, non-cohesive varnish, coating and timber. If too strong water flow is applied, the surface structure can alter or change permanently. In case of doubts we advise to try application of the pressurised-water on the sample where the potential surface disturbance will have no impact on the functionality or appearance of the object.

If you move the nozzle farther from the cleaning object, the pressure of the falling water decreases and the washing effect is less aggressive. On the contrary, movement closer to the object results in higher washing effect along with more aggressive washing effect on the object.

Safety elements




The check valve

The check valve allows a small volume of hot water from the pump without any intervention by its operator in order to protect the pump from overheating. There is no overheating hazard during regular operation, since the pump is fed with a constant supply of cold water to ensure its cooling at the same time. The process of excessive heat-up starts, while the engine is still on and the high-pressure gun is off and there is no water jet coming out of the nozzle. The pump will switch to the internal water circulation mode automatically. The constant circulation of water continues, until the temperature has reached the point for check valve to drain a small amount of hot water in order to ensure infeed of cold water to cool the pump down. That is why **the temperature of water fed into the pump is limited to 40°C only**. If the pressure washer is to remain idle for more than a few minutes, it should be switched off to prevent excessive

load on the check valve and pump.

Pump preparation for the operation

The pump is filled up with the industrial oil. Because of the oil temperature change and thermal expansion during the operation, there is an AIR VALVE (pic. 5-1).



Place the pump to the horizontal position to check the oil level height., otherwise the recorded level will not correspond with the reality. The oil level has to be in the required latitude during the operation, so that the proper lubrication of the internal components is ensured. You can check the oil level on the control sight glass of the pump (picture 5-2). **It must be located close to the mark in the center when the engine is SWITCHED OFF.** If the oil in the pump is necessary to be refilled, use exclusively oil of the class: 15w40 SF-SJ. Do not exceed the maximal oil level! It can cause the damage on the shaft seals and oil leak from the pump.

The pump run without water or dry can cause a permanent damage on the pump and ceases the guarantee. Check the inflow of water before every use!

Regulation of the water pressure in the outlet



This pump enables to regulate the water pressure in the outlet in the scope of 80 Bar - 250 Bar. If you want to change the pressure, turn the controller located on the pump (picture F). Rule: when viewed from the top, the pressure increases if you turn TO THE RIGHT (direction of the watch rotation) and decreases if you turn TO THE LEFT. The engine load and fuel consumption grows with the increased pressure. Because of this fact the water pressure is appropriate to be modified on the base of the particular situation. If you cut down the pressure, you will prolong the service life of the engine and pump.

Maintenance of the pump

Change the oil in the pump after first 5 hours of operation and then every 200 hours of operation. 15W40 the oil of the class

to change it. Release the plug located on the side part of the pump and drain the oil from the pump. Decline the pump, so the oil can pour out completely.

Best practice is to change oil after using a pressure washer, while it is warm, oil leaks more easily and impurities are dispersed in the oil. After the old oil leaks out, screw the plug back.

Pour the oil through the ventilated plug opening of the plug and at the same time check the level on the control sight glass. **Proceed carefully because the oil flows slowly inside the pump and it can often overfill.** After the oil reaches the necessary level, screw the air plug back to the cover of the pump.

Usage of self-priming function of detergent

The pump has self-priming function by use of vacuum from the pot. The black nozzle, determined for the purpose of detergent usage, is needed to start this function. The pump starts to suck the detergent itself through the opening marked by the arrow (pic. F). Apply the detergent by pressing the push button on the gun. **This**

configuration does not serve for creation of active foam. It is necessary to buy a foam lance if we want to create the active foam (category NoSP000-FL002).

Winter storage of the pump

Storage of the pump on places where the environment temperature is under the freezing point can result in unrecoverable damage of the internal components if the pump is not drained properly!

Process of discharging the remaining water from the pump: Make sure that the engine switch (pg. 4 pos. C) is in the position **OFF (0)**. Disconnect the high-pressure hose in the outlet. Then hold the jump start


lever when starting the engine for **10 times** out from the pump through the high-pressure opening in this way. It is not recommended to store the pump in the room where the temperature drops below the freezing point. Any substantial change of the external temperatures can cause water vapour condensation also in the space where water does not get under normal conditions. That can result in internal corrosion and significant reduction of the pump and engine service life.

Charge battery with supplied charger.

Warning! While starting the engine, the gun control lever must be depressed and the water pressure released from the system otherwise battery safety fuse will blow and the starting will be not possible. Blown fuse is not covered by warranty!

Battery

The device comes with a battery charger. Do not use another charger. The battery is hermetically sealed and charging with an unsuitable charger will permanently damage it. Charge the battery to full capacity before using it for the first time.



Connect the charger plug to the mains. The red POWER lamp must light up after connection.

Connect the red connector of the charger to the red contact of the starter (position P) and a black contact on the controller body (position M) or on an unpainted engine block. If the battery is OK, the charging process will start, signaled by the movement of the green light towards the red light (Fig.1). Charging is completed when the green light stops flashing and all four green lights are steady (Fig.2).

The battery is a maintenance-free type with a nominal voltage of 12V and a capacity of 20Ah. Located in the space under the engine mount. It is protected against short circuit by a MIDI 60A fuse. It is located in a black holder in the battery compartment. When replacing, use only a fuse with the same parameters. A voltmeter is located on the battery box. It is used to control the battery voltage and at the same time to control the charging while the engine is running.

Press and hold the red button to activate the voltmeter. Wait a few seconds for the LED to stabilize. If the registered battery status is orange or red with the engine switched off, the battery must be charged with the supplied charger. If the green charge level is registered while the engine is running, everything is OK. If the orange or red LED under the name BATTERY lights up, it is necessary to measure the charge level with a digital voltmeter.

Charging with a charger other than the one supplied may cause irreversible damage to the battery.

There is a 10A blade fuse in the charging circuit in the housing of the switch box. If charging does not work, then the condition of this fuse must be checked. Use only the prescribed current value of 10A.

Problems solution

Problem	Cause	Solution
The pump is not able to create the necessary water pressure, low water flow	1. The nozzle with a big hole is used 2. The water supply is blocked. 3. Low volume of the incoming water 4. Choked the sieve for incoming water 5. The high-pressure hose is choked or the water leaks 6. Too high temperature of the input water 7. The pressure leaks from the gun 8. Choked nozzle 9. Damaged pump	1. Change for the right dimension of the nozzle 2. Check the uncontrolled water flow 3. Use the higher water pressure or the hose with the longer diameter 4. Clean the sieve or replace by a new one 5. Remove the impurities, turn the hose, rinse or replace by a new one 6. Provide the colder water 7. Check the joints tightening, change the gun 8. Clean the nozzle with a steel wire and rinse it with a stream of water 9. Contact the service point
Pump does not take the detergent	1. Wrong nozzle is used 2. Insufficient amount of the detergent in the storage tank 3. The tube is choked	1. Change the high-pressure nozzle for the low-pressure (black) one 2. Check the amount of the detergent 3. Clean the hose with the stream of water, change the suction tube
The engine runs well without the load but it jerks if loaded	1. Low engine revolutions 2. Too high-water pressure 3. Old fuel	1. Modify the position of the speed lever, check the position of the locating screw of the speed lever 2. Cut down the output pressure of the water with the control on the pump according to the instruction on the page 8. 3. Change fuel for fresh one.
The engine stopped during the operation	1. The engine consumed the fuel 2. The spark plug fell out. 3. Low oil level in the engine	1. Fill the tank with the fuel 2. Check the spark plug connector. 3. Check the oil level in the engine
The engine cannot start or it starts but runs jerky	1. Choked air filter 2. The engine is without fuel 3. Old fuel 4. Fuel contaminated with water 5. Wrong proportion of fuel mixture 6. Discharged battery	1. Clean the air filter 2. Fill the tank with the fuel 3. Change the fuel for new one or fill the tank with more new fuel 4. Check spark-plug connector 5. Change the sparking plug for new one 6. Discharge the fuel from the tank and fill in new fuel 7. Contact the service point 8. Charge battery with supplied charger 9. Replace fuse for new MIDI 60A
Engine has no power	1. Choked air filter 2. Old fuel	1. Clean the air filter 1. Fill the tank with the new fuel

Use only original spare parts. You will ensure non-fault conditions for the run of your device in this way.

Guarantee

The guarantee conditions are guaranteed in every country of our distribution network. Potential failures of the appliance will be removed for free during the guarantee period if they are caused by a material or manufacturing defect. Please, contact your seller or the nearest authorized service point with the sales slip of the particular device if you apply the guarantee.

You find the list of the approved service points on our web site: www.waspper.com

The company Waspper s.r.o. try continuously to improve the technical characteristics and user comfort of their products. Because of this reason the producer reserves the right to alter the construction and controls of the device without the previous warning of the final customer. The location of all controls and security elements illustrated in this manual is accurate and realistic. Any design change of the controls does not need to be recorded in this manual.

Technical data

Device type	GP36PD			
Engine type	Peggas 186FA			
Maximal speed	3600 rpm			
Engine type	Four-stroke OHV			
Torque	28,6 Nm/ 2600 rpm			
Power	6.6kW			
Tank capacity	5.5L			
Capacity of the oil filler	1,65L / 10w40			
Water pressure and flow	3600psi/ 248bar 18L/ min			
Net weight	80,5 kg			
Height	96 cm			
Width	57 cm			
Length	76 cm			
Self-priming function of water	Nie			
Fuel consumption	4L/ hour			
Volume of detergent bottle				



EU Declaration of Conformity

The company Waspper s.r.o. hereby declares that the water pumps defined below comply with the relevant EU directives on occupational health and safety of the device operators. Any alteration of the device without the prior consent from the manufacturer will render this declaration void.

Product name: High pressure washer

Type	Serial number	ES inspection report	Noise level measured	Guaranteed noise level
GP36PD	xx0001001-xx9999999	1741/3/2020	106 dB	108 dB
			-	-

Protokol o skúške 6.4.2024 GP36PD zo dňa 6.4.2024

Certificate issued by: TECHNICKÁ INŠPEKCIA a.s., pracovisko KOŠICE, as an accredited inspection body in accordance with EN ISO/IEC 17020

Applicable EU Directives:

2006/42/ES (+2009/127/ES)

2004/108/ES

2000/14/ES

2016/1628/ES

78/2019 Z.z.

Standards applied:

STN EN ISO/IEC 17 020

Producer:

Waspper s.r.o, Duklianska 51, 05201 Spišská Nová Ves, Slovensko

Issued in: Spišská Nová Ves

Issue date: 27.2.2024

Manufacturer's representative: Marián Garbriš

Position: Managing Director

Warranty Certificate

Product type:	WASPPER	Stamp and signature:
Serial number:	Date of purchase:	

In pursuit of service enhancement and simplification of communication with customers, the company Waspper s.r.o. recommends its customers, who purchase this product, to register their product via the manufacturer's website: www.waspper.com. This registration will provide inevitable data for faster processing of your complaints or consulting relevant to purchasing of spare parts and accessories. This registration enables the customer to avoid further procedures, as submitting of the purchase receipt or the warranty certificate.

1. The manufacturer - Waspper s.r.o. - is liable for inherent defects of the product purchased, if such defects become evident within the warranty period. Application of claims for repairs under warranty requires completion and submission of the complaint form via the manufacturer's website: www.waspper.com. The product is covered by a full warranty of 24 months for private customers (as defined by the Civil Code) and 12 months for corporate customers (as defined by the Commercial Code). The warranty period commences upon completion and submission of the complaint report via the website in case of simple defects and damages. The commencement of warranty in case of major defects starts upon the product delivery to the manufacturer's address: Waspper s.r.o., Duklianska 51, 05201 Spišská Nová Ves. Acceptance of complaint will be notified to the customer using the contact details entered in the complaint form.

2. The warranty does not cover defects incurred due to: wrong operation; improper handling or use contradictory to the operation manual or instructions and recommendations from the company Waspper s.r.o.; use or storage of goods within inappropriate areas, especially with respect to temperature, dust formation or ambient humidity; exposure to direct sunlight; damage attributable to natural disasters of force majeure. The warranty does not apply to mechanical damages, any damages due of solid particles, frost or other weather effects. The warranty does not apply to damage to the pump caused by cavitation. Other exemptions from warranty include damages to the engine due to lack of oil and ingress of any other but operating fluid among internal engine components. The warranty doesn't cover also carburetor cleaning and setting, starting rope and starter mechanism damage, blown fuses and filters exchange.

3. Particular steps of claims processing will be notified to the customer following assessment of the scope of repair by the claims engineer. Whenever the replacement of a damaged component can be performed by the customer, the latter will receive a relevant spare part only. If the repair by a servicing centre is inevitable, the customer is obliged to mail the damaged device to the manufacturer's address. The device must be complete (including accessories) and packed properly to prevent its damage during transport, it must be free of mechanical damage and contain no operating fluids. If the goods submitted to the servicing centre shows evident signs of damage or excessive wear, the manufacturer reserves the right to reject such consignment without acceptance.

4. Claims for repairs under warranty oblige the customer to provide the receipt of purchase (invoice, cash receipt) together with the warranty certificate and written description in support of their claim, including photographic documentation. It is recommended to complete the complaint form via the manufacturer's website to ensure the fastest processing of the claim as possible, if the manufacturer acknowledges such claim as justified, the repaired item will be sent to the customer and the postage/freight will be covered by the manufacturer.

5. If the claims engineer finds out the product does not comply qualifications for repair under warranty, the claim will be considered unjustified and the costs of product transport to the customer will be paid by the latter.



6. Should the repair period exceed 30 days or if the product is irreparable, the customer will be offered a replacement item.

7. Justification of claims will be assessed by the claims engineer at the manufacturer. Justified claims will extend the warranty period by the period taken by the claim processing period. Such action will be confirmed to the customer by means of a document in writing, dispatched together with the product or sent via e-mail. If the product subject to claim contains any discontinued component, the manufacturer will provide the customer with an adequate replacement item with its parameters corresponding with the returned product or even better.

8. The customer undertakes to read all the information found on the packaging or in the operation manual; to do so immediately following the product delivery, to acknowledge that preservation of the positive characteristics of the product delivered will be subject to its proper operation and storage. Any disregard to obligations defined herein relieve the company WPW Center s.r.o. from any liability for defects of goods or damages incurred due to breach of this obligation by the customer or any other third party. The customer is obliged to check the intact condition of packaging and product during the purchase and takeover of the consignment from the postman. Any damage to the packaging must be reported to the carrier and recorded immediately. Any damages found only after unpacking of the product must be notified to the distributor within the maximum period of 4 working days. No later claims for product damage can be accepted.

Preparation of the device before the first start!


Check the oil level in the engine



Engine is oil-free from production!


Unscrew the oil plug with a gauge and pour the engine oil supplied with the cleaner. Pour 1,1L oil into the engine. Screw the plug back into the engine. Remove the plug and check whether the level is between the L and H marks.

Preparing the pump for operation



(Figure C) If it's necessary to add oil to the pump, use only the following grades of oil: 15w40 SF-SJ. Do not exceed the maximum oil level! This can result in damage to the shaft seals and oil leakage from the pump. The correct procedure for checking the oil level is given in the section: The Pump.

High pressure nozzle selection



Select the desired Nozzle. The following rule applies: Wider spray angle = larger area of the slide – weaker washing effect. Insert the nozzle into the end of the stainless steel piston rod by pulling the ends outer ring toward the pistol.

Battery level check



A voltmeter is located on the battery box. It is used to control the battery voltage and at the same time to control the charging while the engine is running. Press and hold the red button to activate the voltmeter. Wait a few seconds for the LED to stabilize. If the registered battery status is green, battery charge level is OK. If the registered battery status is orange or red with the engine switched off, the battery must be charged with the supplied charger. If the green charge level is registered while the engine is running, everything is OK.